



Alarm Cleaning

Cleaning The Alarm

If you think your smoke alarm may be contaminated by dust:

1. Turn the mains power **off**
2. Remove the alarm head from the base using the **flat head screwdriver** slot and slide it off
3. Gently shake the alarm head or use a hair dryer on the cool setting to blow the dust out
4. Use a **vacuum cleaner** around the alarm vents
5. Use a damp cloth to clean the cover of the alarm, then dry with a lint-free cloth
6. Slide the alarm head back on the base
7. Switch the mains power back on and ensure the **green** LED light is on



Dust Compensation

Our smoke alarms are fitted with **automatic dust compensation** technology, allowing them to tolerate up to twice as much dust than before. If the dust accumulates to a certain level, the alarm will recalibrate the trigger point.

Dust contamination is **not** covered under warranty, and so any unit affected by dust beyond repair should be replaced.