

# Ei1529RC Hard Wired Alarm Control Switch

## LOCATE ALARM

If the alarms sound, press and release to allow all alarms to be silenced except the alarm sensing fire or carbon monoxide.

## TEST ALARM

Operate monthly to test the alarms.

## SILENCE ALARM

Press to silence nuisance alarms for 10 minutes. This should only be pressed after the 'locate alarm' switch has been used to identify the alarm that has triggered the system, and it is determined that no fire is present.

## MAINS CHECK

The 'test alarm' switch will not sound the alarms in the absence of mains power.

If your alarms are sounding and there is a fire, **evacuate** the premises immediately and call the fire brigade from outside by dialling **999**.

