



Multi-Sensor Fire & CO Alarms

Alarm Identifiers

There are three ways for you to tell what sensors your alarm has.

Vents around the outside of the alarm indicates a **smoke** sensor.

A 'turret' on the front of the alarm indicates a **heat** sensor. You'll be able to see a thermistor underneath it.

If your alarm has a carbon monoxide (**CO**) sensor, it will have three small **holes**.



3000 Series Multi-Sensor CO Alarms



Any multi-sensor 3000 Series alarms with a CO sensor will have LED indicators on the face of the alarm, visible during an alarm activation. One will say '**FIRE**' and one will say '**CO**'. During an activation, either of the **LED lights** will light up to tell you which one it is detecting.

The sounding patterns for fire and carbon monoxide are also different. A fire emergency will sound as a **continuous alarm**. A CO emergency will sound as **three beeps and a pause**.